



"Investigation and Reason Give Understanding"

Search using English Please...

Q

POSTS ~ GROUPS ~ REFERENCE ~ PRIVACY ~ HELP ~



TKZZUO Function Generator Kit Improved Instructions

Save

Table of Contents

Introduction

The XR2206 Function Generator Kit is available through various outlets at a selection of prices up to £13. I got one branded "ARCELI" via Amazon for £7.99.

Having got one, I would advise getting the cheapest one you can. Just take into consideration the trustworthiness of the seller to be sure you get what you've ordered, paid reasonable post and packing charges for, and that you will actually receive it.

Having looked at pictures of the finished article I suspect all brand's circuits are the same but each brand may source their components differently.

Now you can see my other post "<u>A Function Generator Built From A Kit Using An XR2206</u>" to see how I got on with building these kits.

Quality of The Kit Parts

The Electronic Components And Circuit

Board

Manage consent

I the parts to be good. All components were like all those used in modern electronic equipment. All the resistors had the same power handling capacity of a 1/4W. This was reasonable for a low power device such as this XR2206 Function Generator Kit.

Similarly the electrolytic capacitor voltage ratings of 25v was ample.

The preparation of the circuit board was excellent too. Feed-through holes, tinning and lacquering, all looked good to me. Tinning solder had flowed well around the holes.

The Transparent Acrylic Case

All components are attached to the circuit board and the whole is expected to be housed in a Transparent Acrylic Case. This case has six faces all cut out from transparent acrylic sheet 2.5mm thick. The six faces consist of four sides a top (Front Panel) and a Base. The Front Panel is engraved with labels for the controls.

The case is held together around the circuit board by tabs on the edges of the four sides which fit into slots on the Front Panel and Base. The case parts are nicely presented and look as if they were cut out and engraved with a LASER.

The Controls

There are three rotary control knobs (as viewed with the Power Jack on the left):

- The Output Level control is on the left. Weirdly it has to be turned ANT-CLOCKWISE to INCREASE the level.
- 2. The Course Frequency control is in the centre.
- 3. The Fine Frequency control is on the right.

There are two sets of links for controlling Frequency Bands and Waveforms:

- 1. The Frequency Band control is in the form of a five position link:
 - 1. 1Hz-10Hz,
 - 2. 10Hz-100Hz,



- 4. 3kHz 65kHz,
- 5. 65kHz-1MHz.
- 2. There is another link control with two positions:
 - 1. sine wave,
 - 2. triangular wave. This affects the output waveform of the Sine Wave output connection.

The Connections

There are three screw terminals on the right (P1) used for output connections. They are the type which press down on the wire, not the ones where the screw bites into the connection wire and damages it. Top to bottom they are:

- Ground,
- Square Wave,
- Sine or Triangular Wave according to the position of the two position link.

The power is provided from a 9v-12v D.C. supply of the users choosing, via a 5.5mm×2.1mm Power Jack (JK1).


Quality of The Instructions

This is the area that is lacking. The instructions are obviously translated from another language into English. They immediately stand out due to the regular reference to "welding" instead of "soldering". My main reason for writing about this kit is to make the instructions clearer. Here are the original instructions on two sides of an A5 sheet:



XR2206 Function Generator manual install

1. Function Generator component layout diagram



2. The Function Generator component parameter table

Note	label	type	parameters	
R1	resistor	1K	Regardless of the polarity	
R2	Adjustable resistance	8503=50K	(by screen printing layer)	
R3, R5,R6	resistor	5.1K	Regardless of the polarity	
R4	resistor	330	Regardless of the polarity	
R7	Adjustable resistance	8\$03=50K	(by screen printing layer)	
R8	Adjustable resistance	B104=100K	(by screen printing layer)	
C1,	Electrolytic capacitor	100UF	The positive long feet	
C2	non-polar capacitors	1104	Regardless of the polarity	
C3,C4	Electrolytic capacitor	10UF	The positive long feet	
C5	non-polar capacitors	105	Regardless of the polarity	
C6	non-polar capacitors	473	Regardless of the polarity	
C7	non-polar capacitors	,222	Regardless of the polarity	
C8 '	non-polar capacitors	101	Regardless of the polarity	
U1	IC .	XR2206	(by screen printing layer)	
JK1	DC POWER		(by screen printing layer)	
J1	2PIN Jumper cap	XM2.54	Regardless of the polarity	
J2	2PIN Jumper cap	XM2.54	Regardless of the polarity	
P1	Signal wire terminal		(by screen printing layer)	
13	2*5P Jumper cap			

3. The welding installation considerations, follow these steps:

- 1. The components are welding the front board, from low to high principles, namely the first low welding components, such as, capacitor, resistor, diode, etc.
- 2. Welding IC socket, terminal blocks, finally power socket, adjustable potentiometer.
- 3. The back with a diagonal cutting pliers to cut short the plns as far as possible


4. Debugging steps:

- 1. After completion of welding on IC, XR2206, pay attention to the direction of IC, insert the might damage the chip!
- 2. check the IC whether against, such as anti please timely correction.
- 3. Insert the power supply, power supply for 5.5 * 2.1 port, Center positive / barrel negative, For
- 9-12 v power supply voltage. Supply more than 12V, the output waveform is unstable

5. Using the step:

- 1. I1 jumper cap plug in, SIN/TRI blue terminals output sine wave (note I1, I2 can only insert one of)
- 2. 12 jumper cap plug in, SIN/TRI blue terminals output triangular wave (note 11, 12 can only insert one of)
- 3. SQU blue terminals output pulse
- 4. AMP: Sine wave, triangle wave amplitude adjustment
- 5. FINE: Frequency fine adjustment
- 6. Coarse : Frequency of coarse adjustment

6. Schematic diagram of Function Generator



How To Download An XR2206 Data Sheet

The data sheet for the XR2206 is available in HTML or PDF format from <u>ALLDATASHEET.COM</u>. Choose your format from the links in the list below:


- HTML format <u>XR2206 datasheet(1/16 Pages) EXAR | Monolithic Function</u>
 Generator (alldatasheet.com). Having arrived at the webpage you can select the page you want to read from a long line of pages going from left to right.
- PDF format XR2206 pdf, XR2206 Description, XR2206 Datasheet, XR2206 view :::
 <u>ALLDATASHEET :::</u> Having arrived at the webpage either read the data sheet in the online reader or look for the download button to download the PDF file. It is on the right and looks like this:



The XR2206 Function Generator Kit Improved Instructions

XR2206 Function Generator
 Component Layout Diagram

It layout diagram is satisfactory and is almost identical to the image printed on top of the circuit board. So I have photographed the circuit board to display here instead.



A picture of the front of the XR2206 Function Generator circuit board showing how the components are laid out.

2. The Function Generator Component Table

Below I have produced my own table listing the components with their description and value. For non electrolytic capacitors I have also listed the code printed on them.

CONFOREINI	<u> </u>	CODE	<u>VALUE</u>	<u>NOTES</u>
R1	Wire ended resistor	Brown, Black, Black, Brown	1kΩ	Unpolarised
R2 (VR1)	Potentiometer	B503	50kΩ	Unpolarised
R3	Wire ended resistor	Green, Brown, Black, Brown	5.1kΩ	Unpolarised
R4	Wire ended resistor	Orange, Orange, Black, Black	330Ω	Unpolarised
R5	Wire ended resistor	Green, Brown, Black, Brown	5.1kΩ	Unpolarised
R6	Wire ended resistor	Green, Brown, Black, Brown	5.1kΩ	Unpolarised
R7 (VR2)	Potentiometer	B503	50kΩ	Unpolarised
R8 (VR3)	Potentiometer	B104	100kΩ	Unpolarised
C1	Electrolytic capacitor	NO CODE	100μF	Polarised Long wire is +ve
C2	Ceramic capacitor	104	0.1μF	Unpolarised
C3	Electrolytic capacitor	NO CODE	10μF	Polarised Long wire is +ve
C4	Electrolytic capacitor	NO CODE	10μF	Polarised Long wire is +ve
C5	Ceramic capacitor	105	1μF	Unpolarised
C6	Ceramic capacitor	473	47000pF	Unpolarised Manage consent

COIVIF OIVEIVI	<u> PESCRIPTION</u>	CODE	<u>VALUE</u>	NOTES
C7	Ceramic capacitor	222	2200pF	Unpolarised
C8	Ceramic capacitor	101	100pF	Unpolarised
U1	Integrated Circuit	XR2206CP		Notch is between P1 & P16
JK1	Power Socket	NO CODE		5.5mm Outside × 2.1mm Inside
J1-J2	Header Pins & Cap	XM2.54	2×2pin	For Changing Waveform
J3-J7	Header Pins & Cap	XM2.54	5×2pin	For Changing Frequency Range
P1	Output Connectors		3×1term.	Screw Terminal

3. Soldering Instructions



The soldered side of the XR2206 Function Generator Circuit Board after soldering.

- 1. The components are fed from the front of the circuit board (the side with the writing on.) Start with the smaller less sensitive components listed here. After pushing them through their holes splay out their wires to hold them in place while the board is turned over and soldered:
 - 1. Resistors (bend their wires at right angles near to their bodies),
 - 2. Ceramic Capacitors,
 - 3. Electrolytic Capacitors.

2. Solder:

- 1. The IC Socket (align the notch in one end with the picture on the circuit board,
- 2. Blue Terminal Block (ensure the connection holes face the edge of the board,
- 3. Power Socket,
- 4. Potentiometers.
- 3. After soldering, at any stage, cut the unnecessary wires off as close to the board as possible. Any bits that protrude will make the total height Manage consent id

🏭 English

g that the lid (front panel) won't fit. I discovered this the hard way. The tabs on the potentiometers and the power socket must be bent to lie flat. I have acquired small wire cutters which sit very flat against the board and have a spring to open them especially for this work. You can see them below:



Newsome Small Springy Wire Cutters (11cm long).

4. Debugging Stage


- 1. After completion of soldering insert the IC (XR2206) into its socket. Observe its polarity by looking for the notch in one end and align that with the notch in its socket. Also try and take <u>anti-static precautions</u> while doing this. The pins 1 to 8 may need to be straightened and pushed towards pins 9 to 16 to reduce the distance between them. There are plastic tools available to assist with this.
- 2. Connect a 9v to 12v power supply (or battery) to the power socket JK1. JK1 is a standard low voltage power jack with an outer sleeve 5.5mm dia. and a centre pin dia. of 2.1mm **NOTE:** The centre pin is the +ve connection and the outer barrel is the -ve connection. Manage consent




5. Using The XR2206 Function Generator

- 1. With the Jumper Cap (link) in the J1 position the XR2206 Function Generator will produce a Sinewave output at the blue terminal of P1 labelled SIN/TRI.
- 2. With the Jumper Cap (link) removed from J1 position the XR2206 Function Generator will produce a Triangular wave output at the blue terminal labelled SIN/TRI. When choosing this setting the Jumper Cap (link) can be placed in the J2 position to retain it so it doesn't get lost. The pins at the J2 position are not connected to any part of the circuit.
- 3. A Square Wave output is always available at the blue terminal labelled SQU. The mark to space ratio is not adjustable using this kit as provided.
- 4. The AMP (Amplitude) control adjusts the amplitude of the Sine and Triangle wave outputs only. ("See Distorted Sine Wave" produced when the amplitude is set too high in the "Examples of The Waveforms Produced" below.) NOTE: This control is wired in reverse to what is normally expected, such that a CLOCKWISE movement DECREASES the amplitude and an ANTICLOCKWISE movement INCREASES the amplitude. When turned to maximum the sinewave output is very distorted. This can be checked with an oscilloscope.
- 5. There is NO amplitude control for the square wave output. The amplitude is approximately 10.6V Peek to Peek from the one I've measured here (see the 4kHz square wave image below).
- 6. The COURSE control adjusts the frequency generated by large increments.
- 7. The FINE control adjusts the frequency generated by small increments.
- 8. The Jumper Cap (link) J3 can be placed on the 2×5pin block in any of the five positions to change the frequency range covered by the COURSE and FINE controls. The frequency ranges available are marked on the transparent cover and are:
 - 1. 1Hz 10Hz,
 - 2. 10Hz 100Hz,
 - 3. 100Hz 3kHz,
 - 4. 3kHz 65kHz,
 - 5. 65kHz 1MHz.


(The Y scale is in Volts.)




4kHz Sine Wave



4kHz Distorted Sine Wave (Produced when the amplitude is set too high)



4kHz Triangular Wave



6. The XR2206 Function Generator Kit Schematic Diagram